WEEBILL LAB Camera Compatibility List

ZHIYUN

2019.10

Updated on December 12th, 2019 corresponding to the firmware version of stabilizer: 01.04, image transmission firmware version: 01.03.

This compatibility list is only for use with the WEEBILL LAB and is tested by ZHIYUN. Due to the variety of cameras and lenses, ZHIYUN cannot guarantee that all cameras and lenses will be compatible with the WEEBILL LAB. We will continue to test and update the compatibility list.

Brand	Camera Model	Focus(Auto Camera / Control Lens)	Grip Control	APP Control	Support Image Transmission or not	Precautions for normal lens settings	Camera / Lens Control Cable	Firmware Update	Compatible Lens
Sony	A7	○ Take photos ○ Start/stop recording video ○ Shutter speed adjustment ○ ISO adjustment ○ White balance adjustment	○ Take photos ○ Start/stop recording video ○ Aperture adjustment ○ Shutter speed adjustment ○ ISO adjustment ○ White balance adjustment	1. Select MENU > USB Connection > PC Remote. 2. Set the remote camera to remote shooting mode. camera device.	No	/	/	/	FE 16-35mm F2.8 GM FE 24-70mm F2.8 GM Vario-Tessar T* FE 16-35 mm F4 ZA OSS FE 24-105 mm F4 G OSS Distagon T* FE 35 mm F1.4 ZA Sonnar T* FE 55 mm F1.8 ZA FE 70-200mm F2.8 GM OSS Sonnar T* FE 35 mm F2.8 ZA FE 90mm F2.8 Macro G OSS FE 24-240 mm F3.5-6.3 OSS FE 28-70mm F3.5-5.6 OSS FE 50mm F2.8 Macro FE 85mm F1.8 Vario-Tessar T* FE 24-70 mm F4 ZA OSS FE 28-135 mm F4 G OSS FE 50mm F1.8 FE 100-400mm F4.5-5.6 GM OSS FE 400mm F2.8 GM OSS FE 200-600mm F5.6-6.3 G OSS FE 16-35mm f/2.8 GM II FE 24-70mm f/2.8 GM II FE 70-200mm f/2.8 GM OSS II Batis 2/25 CF
	A7II				No				
	A7S				No				
	A7S2				No				
	A7R				No				
	A7R2				No				
	A7R3				No				
	A9				No				
	A6300				No				
	A6500				No				
	A6000				No				
Panasonic	GH5s	Micro USB - TYPE C	○ Take photos ○ Start/stop recording video ○ Aperture adjustment ○ Shutter speed adjustment ○ ISO adjustment ○ White balance adjustment	Set the camera USB mode to PTP(TWAIN).	V1.1	/	/	/	LUMIX G X Vario 35-100mm f/2.8 II POWER O.I.S. LUMIX G X Vario 12-35mm f/2.8 II ASPH. POWER O.I.S. LUMIX G Vario 35-100mm F2.8 POWER O.I.S. LUMIX G Vario 12-60mm f/3.5-5.6 ASPH. MEGA OIS
	GH5				V2.2				
Nikon	Z6	Micro USB-TYPE C	○ Take photos ○ Start/stop recording ○ Manual focus lens ○ Aperture adjustment ○ Shutter speed adjustment ○ ISO adjustment ○ White balance adjustment	Directly connect the port via with the stabilizer	V1.00	/	/	/	AF-S NIKKOR 24mm f/1.8G ED AF-S NIKKOR 35mm f/1.8G ED AF-S NIKKOR 50mm f/1.8G AF-S NIKKOR 85mm f/1.8G Distagon T* ZF.2 35 mm f/2 Makro-Planar T* ZF.2 50 mm f/2
	Z7				V1.02	/	/	/	
	Z50				V1.00	/	/	/	

Note: 1.The table will be updated in time with the firmware and is subject to change without prior notice.

2.Support is shown in the above table.

3.Some cameras may not support the above functions, please refer to the camera operating manual for details.

4. TURN OFF AUTO POWER OFF FUNCTION when connect to the lens wireless control receiver. Please shut off camera power and stabilizer cannot be stored in the camera.

5. Please update the camera and lens to the latest version on the stabilizer when the latest version is released. Please update the camera and lens to the latest video mode, please turn on the stabilizer under video mode and turn off the camera.

6. When the Sony and Nikon camera connect to the WEEBILL LAB under the video mode, the external device is recorded. the external device is not available. When WEEBILL LAB connect to the camera, the camera will not be able to record the video.

7. Panasonic GH5 and GH5s can be updated to firmware 2.0 to support WEEBILL LAB.

Attached Table:

1. The "✓" mentioned at any focal length" means the balance adjustment can be achieved for the both ends of the zoom lens.
2. The "✓" mentioned at "Need to remove eyepiece cover" means the eyepiece cover needs to be removed to achieve focus or zoom control (the installation mode is not fixed and you can try it by yourself).
3. The camera and lens brands and that are not listed in the table can be tested by yourself. The operations and limits that can achieve balance adjustment and when the payload can be mounted on the WEEBILL LAB.

Camera Brand	Camera Model	Lens Type	Installation Method	Balance Adjustment	Need a Camera Working Base or not	Balance Adjustment when Lens Zooming	Follow Focus Motor Can be mounted on the left side	Follow Focus Motor Can be mounted on the right side	Remark
Sony	A7M3	E 16-35mm F4 ZA OSS	Camera only	○	○	Need to remove eyepiece cover	No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 12-24mm F4 G	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 16-35mm F2.8 GM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Vario-Tessar T* FE 16-35mm F4 ZA OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		E PZ 16-50mm F3.5 OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		E 16-55mm F2.8 G	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 24-70mm F4 ZA OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sonnar T* FE 35mm F2.8 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sigma 35mm F1.4 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Distagon T* FE 35 mm F1.4 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 85mm F1.8	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sonnar T* FE 55mm F1.8 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 85mm F1.4 GM	Camera only	○	○	Need to remove eyepiece cover	No	No	The vertical direction of the lens is slightly inclined forward, and the bottom of the lens will be exposed to the side of the camera during move.
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
	A7M2	E 16-35mm F4 ZA OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 12-24mm F4 G	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 16-35mm F2.8 GM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Vario-Tessar T* FE 16-35mm F4 ZA OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		E PZ 16-50mm F3.5 OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		E 16-55mm F2.8 G	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 24-70mm F4 ZA OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sonnar T* FE 35mm F2.8 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sigma 35mm F1.4 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Distagon T* FE 35 mm F1.4 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 85mm F1.8	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sonnar T* FE 55mm F1.8 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 85mm F1.4 GM	Camera only	○	○	Need to remove eyepiece cover	No	No	The vertical direction of the lens is slightly inclined forward, and the bottom of the lens will be exposed to the side of the camera during move.
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
	A7R3	E 16-35mm F4 ZA OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 12-24mm F4 G	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 16-35mm F2.8 GM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Vario-Tessar T* FE 16-35mm F4 ZA OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		E PZ 16-50mm F3.5 OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		E 16-55mm F2.8 G	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 24-70mm F4 ZA OSS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sonnar T* FE 35mm F2.8 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sigma 35mm F1.4 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Distagon T* FE 35 mm F1.4 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 85mm F1.8	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		Sonnar T* FE 55mm F1.8 ZA	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		FE 85mm F1.4 GM	Camera only	○	○	Need to remove eyepiece cover	No	No	The vertical direction of the lens is slightly inclined forward, and the bottom of the lens will be exposed to the side of the camera during move.
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
Panasonic	GH5s GH5	LEICA DG Vario-Elmarit 12-60mm f/2.8-4.0 ASPH.	Camera only	○	○	Need to remove eyepiece cover	No	No	The follow focus motor should be mounted on the left side.
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		LUMIX G X Vario 35-100mm f/2.8 II POWER O.I.S.	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		LEICA DG SUMMILUX 9mm F1.7 ASPH.	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		LUMIX G Vario PZ 14-42mm F3.5-5.6 ASPH. POWER O.I.S.	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		LUMIX G MACRO 30mm F2.8 ASPH. MEGA O.I.S.	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	

Camera Brand	Camera Model	Lens Type	Installation Method	Balance Adjustment	Need a Camera Working Base or not	Balance Adjustment when Lens Zooming	Follow Focus Motor Can be mounted on the left side	Follow Focus Motor Can be mounted on the right side	Remark
Canon	EOS R	EF 16-35mm f/2.8L III USM	Camera only	○	○	Need to remove eyepiece cover	No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		EF 24-70mm f/2.8L II USM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		EF 70-200mm f/2.8L IS III USM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		EF 85mm f/1.4L IS USM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		EF 85mm f/1.2L II USM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
	EOS R	RF 24-105mm f/4L IS USM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		RF 28-70mm f/2L USM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		RF 50mm f/1.8 STM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
Fujifilm	X-T3	XF 16-55mm f/2.8 R LM WR	Camera only	○	○		No	No	The follow focus motor can be mounted on the left side.
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	The follow focus motor can be mounted on the left side.
		XF 50-140mm f/2.8 R LM OIS WR	Camera only	○	○		No	No	The follow focus motor can be mounted on the left side.
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
Leica	SL	Super-ELMAR-SL 24mm f/3.5 ASPH.	Camera only	○	○	Need to remove eyepiece cover	No	No	The follow focus motor can be mounted on the left side.
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		APO-VARIO-ELMARIT-SL 90-280mm f/2.8-4	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		VARIO-ELMARIT-SL 24-90mm f/2.8-4 ASPH.	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
Sigma	fp	45mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		24-70mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		14-24mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		24-105mm F4 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		100-400mm F5-6.3 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		100-400mm F5-6.3 DG DN OS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		150-600mm F5-6.3 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		150-600mm F5-6.3 DG DN OS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		35mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		85mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		105mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		105mm F2.8 DG DN Macro	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		135mm F1.8 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70-200mm F2.8 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70-200mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		60mm F2.8 DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		60mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70mm F2.8 DG Macro	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		20mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		24mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		28mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		40mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		50mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		85mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		105mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		135mm F1.8 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		14-24mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		24-70mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		24-105mm F4 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		100-400mm F5-6.3 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		100-400mm F5-6.3 DG DN OS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		150-600mm F5-6.3 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		150-600mm F5-6.3 DG DN OS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		35mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		85mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		105mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		105mm F2.8 DG DN Macro	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		135mm F1.8 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70-200mm F2.8 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70-200mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		60mm F2.8 DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		60mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70mm F2.8 DG Macro	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		20mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		24mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		28mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		40mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		50mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		85mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		105mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		135mm F1.8 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		14-24mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		24-70mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		24-105mm F4 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		100-400mm F5-6.3 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		100-400mm F5-6.3 DG DN OS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		150-600mm F5-6.3 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		150-600mm F5-6.3 DG DN OS	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		35mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		85mm F1.4 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		105mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		105mm F2.8 DG DN Macro	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		135mm F1.8 DG HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70-200mm F2.8 DG OS HSM	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70-200mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		60mm F2.8 DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		60mm F2.8 DG DN	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		70mm F2.8 DG Macro	Camera only	○	○		No	No	
			With follow focus motor(screen)	○	○		No	No	
			With follow focus motor(without screen)	○	○		No	No	
		20mm F1.4 DG HSM	Camera only	○	○	